

# **DVD VALVES**

## **OPERATION MANUAL**

### **THV – CHV – SHV – KHV – YHV – PHV – VCC – 1" THV AIR VALVE**



### GENERAL SAFETY INSTRUCTIONS

This Operation Manual is created for you to use DVD Air Valves effectively and to reduce potential risks regarding faulty use of the mentioned valves. With this Manual, potential accidents and damages can be prevented and life time of the valve can be increased.

The product you will be using is designed and manufactured according to highest quality standards and has passed DVD quality procedures 100%. However, Valves hold potential risks and can cause danger in case of faulty use or faulty assembly. Therefore, **everyone, who somehow gets in contact with the valve, is responsible for reading and fully understanding this Operation Manual.**

Unauthorized revision, change or application on the product or any of its parts shall be prevented at all times. In case of incompliance to this Operation Manual, DVD Valves cannot be hold directly or indirectly responsible or liable.

During the use of the Valves, general regulations and standards shall be followed. Some of these regulations are defined in EN Standards. Installation of the Valves shall be done by qualified and experienced technical personnel. For detailed information regarding the Valves, DVD Documentation (Catalogs, if appropriate Special Specifications and Technical Drawings, related DVD Order Confirmation etc.) shall be used and followed.

Before disassembling the Valve from the pipeline or any of its parts from the valve, make sure that the pipeline is de-pressurized and necessary safety cautions are taken. **If the line (water or air) is pressurized, any part of the Valve can move unintentionally, without any control.**

After commissioning, consequently the Valves are working under pressure; the Valves shall be monitored at all times and should be inspected regularly. Furthermore; laws, regulations and standards about Occupational Health and Safety should be taken into consideration.

Air Valves are installed on a T-connection, discharge open to atmosphere. Therefore operation of the valve shall be done with extreme caution. Any movement of the valve parts can result in pressurized water discharge and thereby flooding. To prevent flooding, necessary precautions should be taken and Valve chamber should have automated drainage system. Moreover, Valve float mechanism can move without any warning. Necessary protection covers are present to prevent reaching to the moving mechanisms. These protections covers should never be dismantled and reaching to the moving mechanisms should be prevented at all times.

During dismantling of the Valve from the pipeline, medium can flow out from the pipe or the valve, in a fast and uncontrolled way. Before dismantling, the pipeline must be emptied to prevent such an incident. Along with the medium; foreign objects (stone, sand, debris etc.) can be flowing out that can cause damage to personnel. Necessary precautions shall be taken to prevent such damage.

DVD Air Valves are designed to be installed on pipelines via T-Connection, vertical to the ground; and are designed to regulate the air inside the pipelines.

DVD Air Valves are manufactured in different models. Each model has different Valve Characteristic and is appropriate to be used for different air regulation purposes. These Characteristics are summarized as below:

# DVD VALVES OPERATION MANUAL

## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



VALVE CHARACTERISTIC					
MODEL	PRODUCT	FUNCTION	MEDIUM	CAPACITY	CLOSURE TYPE
THV	Single Chamber Air Valve	1 & 2	Potable Water	RB (FB optional)	Classical Type
CHV	Double Chamber Air Valve	1 & 2 & 3	Potable Water	RB (FB optional)	Classical Type
SHV	Non-Slam Air Valve	1 & 2 & 3	Potable Water	FB (DN65, 125 RB)	Non-Slam Type
KHV	Air Valve with Integral Isolation Valve	1 & 2 & 3	Potable Water	RB	Classical Type (Optional NonSlam Type)
YHV	Underground Type Air Valve	1 & 2 & 3	Potable Water	RB	Classical Type
PHV	Sewage Air Valve	1 & 2 & 3	Sewage	RB	Classical Type
VCC	Vacuum Breaker	2	Potable Water	FB	Classical Type
1" THV	1" Single Chamber Air Valve	3	Potable Water	RB	Classical Type

### Function:

1. Function : Venting of air on the start-up of the system, while pipelines are filled.
2. Function : Intake of air on shut-off of the system, while pipelines are drained.
3. Function : Discharge of pressurized air pockets during the operation of the system.

### Capacity:

- FB : Full Bore (Flange nominal size and discharge size are equal)  
 RB : Reduced Bore (Flange nominal size is greater than discharge size)

**For more information regarding the Capacities, please check the DVD Documentation (Catalog). Air Valve selections should be done based on DVD Documentation (Catalog) capacity charts.**

Valve Characteristics can be seen in related DVD Product Documentation (Catalog, if appropriate related specifications, technical drawings, related DVD Order Confirmation etc.). **DVD Air Valves can only be used under defined operating conditions (operating pressure, discharge flow rate, temperature, medium type etc.) and under the defined characteristics. If the project need is noncompliant to these operating conditions or characteristics; pipeline bursts, pipeline rupture, excessive pumping costs or air accumulation problems can be seen.**

Noncompliance to these operating conditions or noncompliant use (valve characteristic) can cause permanent damage to the Valve. Operating conditions and valve characteristics are calculated and defined individually for every project. If you do not have any knowledge of these Operating Conditions or Characteristics, or if the conditions of the project are changed, please contact the manufacturer immediately.

Operating limits such as Nominal Size, Pressure, Operating Temperature of the Valve can be found in DVD Documentation. Furthermore; Operating Size, Operating Pressure, Valve Body Material and Production Date can be found on the marking of the Valve Body. Any operating condition that is in compliant with these operating limits shall be approved by the Manufacturer

*All materials are subject to change without notice.*

*DVD Valves shall not be liable for any errors contained herein.*

## DVD VALVES OPERATION MANUAL

### THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



in written. Pipeline Operating Pressure can be fluctuating (due to surge, water hammer, air regulation problems etc.). Therefore, such fluctuations should be considered, and the Valve should never be faced with a higher pressure than the defined Nominal Pressure.


Valves should be protected from frosting at all times. Especially in locations that have high risk, protective measures should be taken such as; burying of pipelines in more depth, protecting the valve chambers by isolation material, or fully draining of pipelines before freezing conditions occur. If no precaution is taken, due to expansion of water, Valve body or other parts of the Valve can be permanently damaged. DVD Valves cannot be held liable from such damages.

## TRANSPORTATION AND STORAGE

During transportation and storage, Valves shall be packed with material that can withstand to its size and weight, and should be fully fixed on a pallet. If the Valves are not fully fixed on the pallet, the Valve can move during transportation and can cause severe damage. The Valve should be protected from environmental conditions and physical impacts from outside. Any part of the Valve body should not exceed the pallet dimension and shall be wrapped by protective cover (stretch film, insulation material etc).

Valve coating and Valve accessories shall be protected at all times during transportation and assembly.

For Valves of sizes DN150 and above, Positioning of the Valve on the pallet is on its flange, fixed to the pallet. For Valves of sizes below DN150, Positioning of the Valve on the pallet is as laid down.



<DN200



>DN150

PICTURE 1: Positioning of the Valve on the Pallet

Center of Gravity of the Valve can be away from the Valve Center. Therefore, during lifting the Valve, it can swing around. Such incidents can cause damage on the lifting device, the Valve itself, and to the personnel around the Valve. **Lifting operation should be done with extreme care and Center of Gravity of the Valve should be determined before lifting operation.**

In CHV Double Chamber Air Valve models; be cautious about the extra weight of the second chamber and its effect on the center of gravity. This chamber can cause the Valve to tilt down, especially at small sizes. Therefore, small sizes of these models are advised to be stocked as laid down to the pallet.

Lifting Belts and Lugs that are according to safety norms shall be used. They have to be suitable for the Valve weight. Valves of sizes DN200 and above should be lifted only from the Eye-Bolts.

**Lifting from the Cover, Cover Studs or Filter should not be done at all times.** These parts are not designed to carry the weight of the Valve and lifting from these parts can cause breaking, tumbling or dropping.

**During Storage and Transportation, Valves should never be faced with direct sunlight.** Under direct sunlight; seals or valve coating can get damaged. Valves should be protected and stored in a dry and aerated environment and should be protected from environmental effects. Storage should be done @ -20°C/+50°C temperature range. If the temperature is below 0°C, before assembling the Valve; the Valve should be heated up to 5°C.

Valves should never be in direct contact with the ground, and should be protected by a pallet. Valve internal surface and moving parts should be protected from foreign particles, sand, dirt, debris etc. Debris collected on moving parts can cause these parts to get stuck and prevent valve operation. Flange Protection Covers should only be dismantled right before assembly to the pipeline.

## USE AND APPLICATION

**Minimum operating pressure of DVD Air Valves is 0.2 bar.** Below 0.2 bar applications, Air Valve is not guaranteed to provide sealing and there can be water spillage. In such low pressure applications, Air Pipes use is recommended.

All DVD Air Valve Models other than PHV Sewage Air Valves (THV, CHV, SHV, KHV, YHV, 1"THV, VCC) are designed to be used in clean potable water systems. Operation in medium containing oil or lubricants is only possible with written manufacturer approval and with special material selections suitable to the medium.

**In systems that contain foreign particles (dirt, sand, debris etc.), the Valve can be clogged or sealing problems can occur.** None of the DVD Air Valve Models other than PHV Sewage Air Valves can be used in such systems.

Pipeline protection by using Air Valves is only possible if all below conditions are valid:

- Correct air valve model selection,
- Correct air valve size selection,
- Correct air valve positioning on the pipeline (place and quantity).

**DVD Valves cannot be held responsible from any problems that can occur due to wrong project design, wrong air valve model selection, wrong air valve size selection or wrong air valve positioning.** If there is a doubt about project selection, all project data should be sent to DVD Valves and should be approved in written.

**Filling and emptying the pipeline should be done in a controlled manner. Excessive Water Filling Velocity can result in pre-mature closure of Air Valves. Likewise, Excessive Water Drainage Velocity can result in inadequate air intake and pipeline rupture.**

To prevent such incidents, System Pressure should be checked during these processes. During pipeline water filling, differential pressure between the atmospheric pressure and the pressure


## DVD VALVES OPERATION MANUAL

### THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE




inside the pipeline should be at most 0.3 bar. And during pipeline water emptying, differential pressure between the atmospheric pressure and the pressure inside the pipeline should be at most 0.4 bar.

While confirming with the above conditions, if water filling velocities go higher than 0.25 m/sec; to prevent slamming, Immersion Pipe Application is recommended.



PICTURE 2: Immersion Pipe Application

If the Valve is not actively used for a long time (either in fully open or fully closed position), Valves are recommended to be manually operated at least every six months. Long time of non-operation increases the potential of blocking in the Valve. Inspection can be done using the Isolation Valve in the upstream of the Air Valve and by the Optional Test Cocks located on the Air Valve body.




PICTURE 3: Optional Testing Cocks



## **INSTALLATION TO THE PIPELINE**

The T-connected pipeline flange should be horizontally positioned and should be parallel to the earth. Even if the pipeline profile is sloppy, Air Valve positioning should be done vertical to the earth. **Non-vertical installations of the Valve can cause malfunction of the Valve. DVD Valves cannot be held liable from such malfunction due to wrong installation.**

Load forces transmitted to the Valve from the pipeline should not go beyond what is defined in EN 1074-2 standard. Not to do so can cause Valve failure. During installation, make sure that flange surfaces are clean and smooth.



PICTURE 4 – Air Valve Installation on a Sloppy Pipeline Profile

Valve flange to pipeline flange connection should be done by bolts and nuts; and washers must be used to protect the Valve coating. Opposing bolts should be screwed equally, preventing high load forces, strain and failure. Steel reinforced gaskets should be used between the flanges. Make sure that the gaskets are correctly positioned on the sealing surface of the flanges. Flange bolting should be selected according to EN 1591 Standard requirements. Excessive screwing of the bolts can cause permanent damage on the Valve.

Air Valves should be installed as close to the main pipeline as possible and T-connection length should be minimized. Otherwise Air Valve reaction speed increases, and frost risk is increases as well.

Valve should be protected from outside effects (construction work, coating, concrete work etc.) at all times. Welding work should be concluded before Valve installation, and welding burrs should be cleaned beforehand.

**Pipeline should be flushed and cleaned from all foreign particles, before Valve installation.**

Even though the pipeline can seem to be clean around the Valve installation area, during filling the line, particles from long distances can be carried to the installation area and can cause permanent damage on the Valve. DVD Valves cannot be held liable from damages occurred due to foreign particles such as debris, dirt, stones, wooden sticks etc.

**Air Valves have small air discharge orifices which contain a potential clogging risk if the medium is not clean. DVD Valves cannot be held liable from malfunctioning of the Valve due to residual clogging of these orifices.**

Especially at steel pipeline applications, make sure to have full cathodic protection. In the absence of cathodic protection or non-active protection, Galvanic Corrosion can occur very fast. DVD Valves cannot be held liable from such damages.

Inspect the Valve before installation and make sure that there are no foreign particles inside the Valve. Check the sealing surfaces of the Valve and confirm that they are clean. For Valves that are stored for a long period of time, please check the sealing gasket for any deformation and please contact the manufacturer if you see any problems.

If the Valve needs to be re-coated on site, for maintenance purposes, be sure to protect the sealing surfaces (gaskets, o-rings, stainless steel surfaces etc.) If these surfaces are coated, sealing problems can occur.

## VALVE POSITIONING

All models of Air Valves other than YHV Model are designed to be installed above ground and should be protected by a Valve Chamber. YHV Underground Air Valve is designed to be buried underground and do not require a Valve Chamber. Any other installation can cause malfunctioning of the Valve.

Air Valves discharge or intake air from/to the pipeline. Therefore Valve Chamber should have enough aeration capacity; otherwise Air Valve capacity can be constrained.

Make sure that the Valve Chamber has enough drainage system. Otherwise Air Valve can be flooded, which can cause contaminated water to penetrate inside the pipeline, or can cause air intake function of the Air Valve to fail.

Air Valves can spill some water out of the pipeline, in cases of sudden water column movement. Precautions should be taken for such incidents and enough drainage system should be constructed.


**During installation, take into consideration possible inspection and maintenance circumstances and provide enough space for such intervention. An Isolation Valve (Gate Valve, Ball Valve or Butterfly Valve) should be installed in the upstream of the Air Valve.**

Make sure that the Isolation Valve is full bore and does not limit the air capacity of the Air Valve. In small size applications, Butterfly Valves are not recommended to be used as Isolation Valves. YHV Underground Air Valves do have an integral isolation valve and does not require an extra external Isolation Valve to be installed with it.

**After commissioning the Air Valve, make sure that the Isolation Valve is fully opened. Closed or Semi-open Isolation Valves directly influence the Air Valve capacity and can endanger the pipeline safety.**

Lifting Device should be available on the site that is in line with the weight of the Valve. Otherwise, dismantling and re-installing of the Valve for maintenance purposes will not be possible.






PICTURE 5 – Air Valve + Isolation (Service) Valve Connection

Air Valves should be positioned on the pipeline, analyzing each single project data individually. This work should be correctly done by the design office. However, typical locations of Air Valves are in high elevation points, slope angle changing points, branch distribution points, road/river transition points, pump stations, every 400 meters in continuous pipelines, and more.

**DVD Valves cannot be held liable from any damages that can occur due to wrong project design, wrong air valve model selection, wrong air valve size selection or wrong air valve positioning.** If there is a doubt about project design, all available project data should be sent to DVD Valves for analysis and written approval should be received from the DVD.




PICTURE 6 – Typical Air Valve Positioning on a Pipeline Profile – **Each Project should be Analyzed and Positioning should be Done Accordingly!**

## DVD VALVES OPERATION MANUAL

### THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



Air Valves are recommended to be installed on correctly sized Ventilation Domes. Typical ventilation dome sizing are provided as below. In main pipeline sizes of DN600 and above, a Drainage Valve installation on the Ventilation Dome is recommended. Drainage Valve can be used for manual air discharge or air intake.



PICTURE 7 – Ventilation Dome Application and Air Valve Installation

## MAINTANANCE

**Before starting the maintenance, make sure that the Valve is isolated; upstream pipeline of the Valve is drained and de-pressurized.** In case pipeline is not de-pressurized fully; potential dangers such as sudden disc movement, part movement or pressurized water outflow etc. can occur.

After maintenance is done, please re-install the Valve to the pipeline according to the related section in this Operation Manual.

Maintenance work should be done by experienced and skilled personnel. If there is no such personnel, please get in contact with DVD Valves and request your maintenance need. All personnel who will do the maintenance work should read and fully understand this Operation Manual.


Maintenance personnel should follow Occupational Health and Safety requirements and should use the necessary protective accessories (Work shoes, glasses, helmet, gloves etc.).

# DVD VALVES OPERATION MANUAL

## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



DVD THV Single Chamber Air Valve Spare Part lists and predicted life time of these parts are indicated as below:



**NOTE:**

PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS. CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME.

9	4		SCREW	8:8 Gal.	5 YEARS	
8	4		WASHER	SS 304	5 YEARS	
7	1		COVER O-RING	EPDM	3 YEARS	
6	1		LARGE ORIFICE FLOAT O-RING	EPDM	3 YEARS	
5	1		LARGE ORIFICE	Brass	10 YEARS	
4	1		CAGE	Polyamid-6	5 YEARS	
3	1		LARGE ORIFICE FLOAT	Polyethylene	5 YEARS	
2	1		COVER	GG-25 /GGG 40	10 YEARS	
1	1		BODY	GG-25 /GGG 40	10 YEARS	
MONTAJ	QTY.	PART NO	PART NAME	MATERIAL	PART LIFE TIME	NOTE
DRAWING NO		DN 40-80 SINGLE CHAMBER AIR VALVE				<div>REV. DATE</div> <div>REVISION</div> <div>SHEET</div>
--						
SIZE	A3					
SCALE	DESIGN	Nuray KAFADAR		DRAWING DATE		00
1:1	APPROVED	Alaattin YILDIRIM		23.04.2009		00/21

All materials are subject to change without notice.


DVD Valves shall not be liable for any errors contained herein.

# DVD VALVES OPERATION MANUAL



## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



DVD CHV Double Chamber Air Valve Spare Part lists and predicted life time of these parts are indicated as below:



NOTE:  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS.  
CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME.

19	1		SMALL CHAMBER BOX O-RING	EPDM	3 YEARS	
18	4		WASHER	SS 304	5 YEARS	
17	4		IMBUS SCREW	8:8 Gal.	5 YEARS	
16	1		SMALL CHAMBER BOX	GG-25 /GGG 40	10 YEARS	
15	2		O-RING	EPDM	3 YEARS	
14	1		SMALL ORIFICE COVER	Brass	5 YEARS	
13	1		PIN	Brass	5 YEARS	
12	1		SMALL ORIFICE	Brass	5 YEARS	
11	1		SMALL ORIFICE GASKET	EPDM	3 YEARS	
10	1		SMALL ORIFICE FLOAT	Polyethylene	5 YEARS	
9	4		SCREW	8:8 Gal.	5 YEARS	
8	4		WASHER	SS 304	5 YEARS	
7	1		COVER O-RING	EPDM	3 YEARS	
6	1		LARGE ORIFICE FLOAT O-RING	EPDM	3 YEARS	
5	1		LARGE ORIFICE	Brass	10 YEARS	
4	1		CAGE	Polyamid-6	5 YEARS	
3	1		LARGE ORIFICE FLOAT	Polyethylene	5 YEARS	
2	1		COVER	GG-25 /GGG 40	10 YEARS	
1	1		BODY	GG-25 /GGG 40	10 YEARS	
MONTAJ	QTY.	PART NO	PART NAME	MATERIAL	PART LIFE TIME	NOTE
DRAWING NO		DN 40-80 DOUBLE CHAMBER AIR VALVE				 DOGUS VANA SANAYI
--						
SIZE	A3					REV. DATE
SCALE	DESIGN	Nuray KAFADAR		DRAWING DATE	00	
1:1	APPROVED	Alaattin YILDIRIM		23.04.2009	00/21	

All materials are subject to change without notice.


DVD Valves shall not be liable for any errors contained herein.

# DVDVALVES OPERATION MANUAL


## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



DVD SHV Non-Slam Air Valve Spare Part lists and predicted life time of these parts are indicated as below:



NOTE:  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS  
CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS  
PART LIFE TIME

19			BOLT	AISI 304	5 YEARS				
18			O-RING	EPDM	3 YEARS				
17			O-RING	EPDM	3 YEARS				
16			WASHER	AISI 304	5 YEARS				
15			NUT	AISI 304	5 YEARS				
14			STEM	AISI 304	5 YEARS				
13			O-RING	EPDM	3 YEARS				
12			SCREW	AISI 304	5 YEARS				
11			WASHER	AISI 304	5 YEARS				
10			FILTER COVER	AISI 304	5 YEARS				
9			FILTER	AISI 304	5 YEARS				
8			SMALL ORIFICE	Brass	5 YEARS				
7			ORIFICE GASKET	EPDM	3 YEARS				
6			INTRODUCTION ORIFICE	AISI 304	5 YEARS				
5			TOP FLOAT	Polyethylene	5 YEARS				
4			MIDDLE FLOAT	Polyethylene	5 YEARS				
3			LARGE FLOAT	Polyethylene	5 YEARS				
2			COVER	AISI 304	5 YEARS				
1			BODY	GGG40	10 YEARS				
Mon. No	QTY	PART CODE	PART NAME	MATERIAL	PART LIFE TIME	NOTE			
			Ürün Adı: <b>NON-SLAM AIR VALVE</b>			<b>dVd</b> <b>DOĞUS VANA SANAYİ</b>  DRAWING NO <b>SHV</b>			
Date	19-02-2016	Signature							
Design	Nuray KAFADAR								
Approved	Alaattin YILDIRIM		SIZE	A3	SCALE	WEIGHT			
 GENERAL TOLERANCE ISO 2768-M			0-6	6-30	30-120	120-400	400-1000	1000-2000	2000-4000
			±0.1	±0.2	±0.3	±0.5	±0.8	±1.2	±2

All materials are subject to change without notice.

DVD Valves shall not be liable for any errors contained herein.

DVD VALVES OPERATION MANUAL  
THV/CHV/SHV/KHV/YHV/PHV/VCC/1”THV AIR VALVE



DVD KHV Double Chamber Air Valve w/ Isolation Valve Spare Part lists and predicted life time of these parts are indicated as below:

NOTE: PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS. CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME.									
30	1	SETSCREW	8.8 Gal.	5 YEARS					
29	1	CAP TOP	GG-25 (GGG 40)	10 YEARS					
28	4	SCREW	8.8 Gal.	5 YEARS					
27	1	WASHER	SS 304	5 YEARS					
26	1	O-RING	EPDM	3 YEARS					
25	3	O-RING	EPDM	3 YEARS					
24	1	STEM NUT	Brass	5 YEARS					
23	1	STEM	SS 420 (X20 Cr13)	5 YEARS					
22	1	MIDDLE COVER	GG-25 (GGG 40)	10 YEARS					
21	1	MOVEMENT NUT	Brass	5 YEARS					
20	1	VULCANIZED WEDGE	GGG 40+EPDM	5 YEARS					
19	1	SMALL CHAMBER COVER O-RING	EPDM	3 YEARS					
18	4	WASHER	SS 304	5 YEARS					
17	4	SCREW	8.8 Gal.	5 YEARS					
16	1	SMALL CHAMBER COVER	GG-25 (GGG 40)	10 YEARS					
15	2	O-RING	EPDM	3 YEARS					
14	1	SMALL ORIFICE COVER	Brass	5 YEARS					
13	1	PIN	Brass	5 YEARS					
12	1	SMALL ORIFICE	Brass	5 YEARS					
11	1	SMALL ORIFICE GASKET	EPDM	3 YEARS					
10	1	SMALL ORIFICE FLOAT	Polyethylene	5 YEARS					
9	4	SCREW	8.8 Gal.	5 YEARS					
8	4	WASHER	SS 304	5 YEARS					
7	1	COVER O-RING	EPDM	3 YEARS					
6	1	LARGE ORIFICE FLOAT O-RING	EPDM	3 YEARS					
5	1	LARGE ORIFICE	Brass	10 YEARS					
4	1	CAGE	Polyamid-6	5 YEARS					
3	1	LARGE ORIFICE FLOAT	Polyethylene	5 YEARS					
2	1	LARGE ORIFICE COVER	GG-25 (GGG 40)	10 YEARS					
1	1	BODY	GG-25 (GGG 40)	10 YEARS					
ITEM	QTY.	PART NO	PART NAME	MATERIAL	PART LIFE TIME	NOTE			
DRAWING NO									
-									
SIZE	A3	DN 50-65-80 DOUBLE CHAMBER AIR VALVE WITH ISOLATION VALVE							
SCALE	DESIGN	DOĞUŞ VANA SANAYİ							
1:1	APPROVED	Nurey KAYADAR	DRAWING DATE	27.04.2009	REV. DATE	00	REVISION	00/21	SHEET



DVD VALVES OPERATION MANUAL  
THV/CHV/SHV/KHV/YHV/PHV/VCC/1”THV AIR VALVE



DVD YHV Underground Air Valve Spare Part lists and predicted life time of these parts are indicated as below:

Diagram showing the internal components of the DVD YHV Underground Air Valve, numbered 1 through 26.

NOTE:  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME

Part No	QTY	PART CODE	PART NAME	MATERIAL	PART LIFE TIME	NOTE
26			WASHER	ALSI 304	5 YEARS	
25			NUT	ALSI 304	5 YEARS	
24			SCREW	ALSI 304	5 YEARS	
23			SCREW	ALSI 304	5 YEARS	
22			SCREW	ALSI 304	5 YEARS	
21			WASHER	ALSI 304	5 YEARS	
20			SCREW	ALSI 304	5 YEARS	
19			O-RING	EPDM	3 YEARS	
18			O-RING	EPDM	3 YEARS	
17			FIXING PIN	ALSI 304	5 YEARS	
16			DRAINAGE COLLECTOR	Plastic	5 YEARS	
15			SEALING RING	EPDM	3 YEARS	
14			SPRING	ALSI 302	5 YEARS	
13			SCREW	ALSI 304	5 YEARS	
12			SPRING SHAFT	X20Cr13	5 YEARS	
11			CHECKVALVE CASE	X20Cr13	5 YEARS	
10			SCREW PRESSURE PART	X20Cr13	5 YEARS	
9			1" PIPE	8/8 GAL	10 YEARS	
8			T- NUT	GGG 40	3 YEARS	
7			POWDER COVER	Aluminium	3 YEARS	
6			AIR VALVE CASE	Aluminium	3 YEARS	
5			PRESSURE PART	Bronze	5 YEARS	
4			SEAT O-RING	ALSI 304	5 YEARS	
3			FLANGED PIPE	Plastic	5 YEARS	
2			AIR VALVE	GGG 40	10 YEARS	
1			BODY	GGG 40	10 YEARS	

From Add:

UNDERGROUND AIR VALVE

DVD

DOĞUS VANA SANAYİ

YHV


YHV

Date	19-02-2016	Signature	
Design	Nura KAYADAR		
Approved	Aladdin YILDIRIM		
Scale	0-6	A3	SCALE
Weight	120-400	400-1000	1000-2000
Material	GGG 40	GGG 40	GGG 40
Part Life Time	5 YEARS	5 YEARS	5 YEARS

# DVD VALVES OPERATION MANUAL

## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE

DVD PHV Sewage Air Valve Spare Part lists and predicted life time of these parts are indicated as below:



**NOTE:**  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS. CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME.

ITEM	QTY.	PART NO	PART NAME	MATERIAL	PART LIFE TIME	NOTE
21	1		R 1/2" BALL VALVE	BRASS	5 YEARS	
20	1		R 1/2" NIPPLE	BRASS	10 YEARS	
19	1		R 1/2" PLUG	BRASS	10 YEARS	
18	1		DN32 - PVC - ELBOW	PVC	5 YEARS	
17	1		DN40 - PVC - PIPE	PVC	5 YEARS	
16	1		O-RING	NBR	2 YEARS	
15	1		ADAPTOR COVER	PVC	10 YEARS	
14	1		O-RING	NBR	2 YEARS	
13	1		ADAPTOR	PVC	10 YEARS	
12a	1		SEALING GASKET	PVC	2 YEARS	
12	1		SEALING GASKET HOLDER	PVC	10 YEARS	
11	1		SEALING GASKET ASSEMBLY	EPDM	2 YEARS	
10a	1		WASHER	PVC	10 YEARS	
10	1		COUNTERNUT	SS 304	10 YEARS	
9	1		NUT	BRASS	10 YEARS	
8	8		SCREW	SS 304	10 YEARS	
7	8		WASHER	SS 304	10 YEARS	
6	1		O-RING	NBR	10 YEARS	
5	1		NUT	SS 304	10 YEARS	
4	1		STEM	X30Cr13	10 YEARS	
3	1		FLOAT	SS 431	10 YEARS	
2	1		COVER	GG25/GG40	10 YEARS	
1	1		BODY	GG25/GG40	10 YEARS	

**DRAWING NO**

**SIZE** A3

**SCALE** 1:1

**DESIGN** Nurey KAYADAR

**APPROVED** Alattin YILDIRIM

**DRAWING DATE** 23.04.2009

**SEWAGE AIR VALVE**

**DOĞUS VANA SANAYİ**  
**R/D**

**REV. DATE** 00

**REVISION**

**SHEET** 00/21

DVD VALVES OPERATION MANUAL  
THV/CHV/SHV/KHV/YHV/PHV/VCC/1”THV AIR VALVE



DVD VCC Vacuum Breaker Spare Part lists and predicted life time of these parts are indicated as below:

NOTE:  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME

24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
THREADED NUT	KEY	SETScrew	SCREW	SCREW	COUNTER WEIGHT LEVER	COUNTER WEIGHT	O-RING	O-RING	THREADED NUT	SCREW	WASHER	COVER	O-RING	SHAFT	NUT	WASHER	SEALING DISC	STEM	SEALING DISC LEVER	BODY SEAL	BODY		
BRASS	C45	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	EPDM	EPDM	BRASS	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304	AINI 304
10 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	3 YEARS	3 YEARS	10 YEARS	5 YEARS	5 YEARS	10 YEARS	10 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	5 YEARS	10 YEARS	10 YEARS	10 YEARS	10 YEARS




DATE: 19-02-2016  
DESIGN: NUREY KAFADAR  
APPROVED: MAMUR YILDIRIM  
GENERAL TOLERANCE: ISO 2768-M

SIZE: 0-6  
SCALE: A3  
WEIGHT: 120-400  
DRAWING NO: DVD  
VCC

# DVD VALVES OPERATION MANUAL

## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE

DVD 1" THV Single Chamber Air Valve Spare Part lists and predicted life time of these parts are indicated as below:

**NOTE:**  
PART LIFE TIME IS AN ASSUMPTION IN NORMAL OPERATING PRESSURES AND NORMAL OPERATING CONDITIONS.  
CIRCUMSTANCES THAT CAN OCCUR DUE TO FALSE OPERATION OR INAPPROPRIATE CONDITIONS ARE NOT EVALUATED AS PART LIFE TIME.

ITEM	QTY.	PART NO	PART NAME	MATERIAL	PART LIFE TIME	NOTE
15	1		CONNECTION PIECE	Brass / N/A Bronze	3 YEARS	
14	1		CONNECTION FLANGE	ST 37 Steel	5 YEARS	
13	1		BALL VALVE	Brass	5 YEARS	
12	1		NIPPLE	Brass	5 YEARS	
11	6		WASHER	SS 304	5 YEARS	
10	6		SCREW	8.8 Gal.	5 YEARS	
9	1		COVER O-RING	EPDM	3 YEARS	
8	1		SMALL ORIFICE COVER	Brass	5 YEARS	
7	1		O-RING	EPDM	3 YEARS	
6	1		PIN	Brass	5 YEARS	
5	1		SMALL ORIFICE	Brass	10 YEARS	
4	1		SMALL ORIFICE GASKET	EPDM	3 YEARS	
3	1		ORIFICE FLOAT	Polyethylene	5 YEARS	
2	1		COVER	GG-25 / GG-40	10 YEARS	
1	1		BODY	GG-25 / GG-40	10 YEARS	

**DRAWING NO** --

**SIZE** A3

**SCALE** 1:1

**DESIGN** APPROVED

**DATE** 27.04.2009

**DN 25 SINGLE CHAMBER AIR VALVE**

**REV. DATE** 00

**REVISION** 00/21

**SHEET**

PICTURE 8 – DVD Air Valves Spare Part List and Predicted Life Time

All materials are subject to change without notice.

DVD Valves shall not be liable for any errors contained herein.

# DVD VALVES OPERATION MANUAL

## THV/CHV/SHV/KHV/YHV/PHV/VCC/1"THV AIR VALVE



This table is to provide a general idea to users, and life times can vary according to site conditions, application and operational conditions. Sealings should be changed when they are worn out or damaged.

All gasket and o-rings should be lubricated after renewal (w/ de-mineralized lubricant). If the Valve is potable water approved, potable water approved lubricants should be used.

Please follow the below steps to renew the DVD THV, CHV, SHV, KHV Cover Sealing (7, 7, 17, 7):

1. Isolate the Valve from the line, and drain the water. Make sure to fully de-pressurize the pipeline.
2. Remove the bolting on the Cover (2) and take it out from the Body.
3. Remove the Cover Sealing (7, 7, 17, 7).
4. Clean the Body (1) sealing surface and Cover (2) sealing surface. In THV, CHV and KHV models, clean the surface of the Disc (5).
5. Make sure that there are no residuals or particles inside the Valve body. If so, please clean them.
6. Check the Float movement and make sure that it is moving freely.
7. Install the new Cover Gasket (7, 7, 17, 7) on the body. Make sure that the gasket perfectly fits on the housing.
8. Install the Cover (2) on the Body (1) and screw the bolts in opposing order.

Please follow the below steps to renew the Big Float Sealing Gasket (6, 6, 13&18, 6) in THV, CHV, SHV, KHV models:

1. Isolate the Valve from the line, and drain the water. Make sure to fully de-pressurize the pipeline.
2. Remove the bolting on the Cover (2) and take it out from the Body. In SHV models, all the Float Assembly shall come out together with the Cover (2).
3. Remove the Cover Sealing (7, 7, 17, 7). In THV, CHV and KHV models, remove the Disc (5) as well.
4. Clean the Body (1) sealing surface and Cover (2) sealing surface. In THV, CHV and KHV models, clean the surface of the Disc (5).
5. Remove the Big Float Sealing Gasket (6, 6, 13&18, 6):
  - a. In THV, CHV and KHV models, take out the Big Float (3) from the Float Guiding Cage (4) and remove the Float Sealing Gasket (13&18).
  - b. In SHV models, remove the Studs (14) from the Cover (2) and take out the Floats from Studs. Remove the Float Sealing Gaskets (13&18).
6. Clean the Float (3, 3, 4&7, 3) sealing surfaces.
7. Install the new Float Sealing Gasket (6, 6, 13&18, 6) on the Float. Make sure that it fits perfectly to the housing.
8. Install the Floats (3, 3, 4&7, 3) inside the Float Cage (4, 4, 14, 4).
9. Install the Float Cage:
  - a. In THV, CHV and KHV models, install the Float Cage (4, 4, 14, 4) to the Body (1).
  - b. In SHV models, assemble the Cage Studs (14) to the Cover (2).
10. Check the Float movement and make sure that it is moving freely.
11. Make sure that there are no residuals or particles inside the Valve body. If so, please clean them.
12. Install the new Cover Gasket (7, 7, 17, 7) on the body. Make sure that the gasket perfectly fits on the housing.
13. Install the Cover (2) on the Body (1) and screw the bolts in opposing order.

Please follow the below steps to renew the Dynamic Float Sealing Gasket (7, 11):

1. Isolate the Valve from the line, and drain the water. Make sure to fully de-pressurize the pipeline.
2. Take out the Dynamic Float Assembly out of the Valve Body (1):
  - a. In 1" THV, CHV and KHV models, disassemble the bolting of the Small Chamber Box (16) and take it out.
  - b. In SHV models, disassemble the bolting of the Cover (2) and take it out. All Float Assembly shall come out as one item.
3. In 1" THV, CHV and KHV models, take out the Small Chamber Box Sealing (19). In SHV models, take out the Cover Sealing (17).
4. Clean the Body (1) sealing surface and Cover/Small Chamber Box (2, 16) sealing surface.
5. Remove the Dynamic Float Sealing Gasket (7):
  - a. In 1" THV, CHV and KHV models, secure the Small Chamber Box (16) and dismantle the Small Orifice Body (12) and Cover (14). Pull out the Dynamic Float Sealing Gasket (7) from the Small Float (10).
  - b. In SHV models, remove the Studs (14) from the Cover (2) and take out the Floats from Studs. Pull out the Dynamic Float Sealing Gasket (7) from the Dynamic Float (3).
6. Clean the Dynamic Float (10, 3) sealing orifice (12, 8) and make sure that there are no residuals on it.
7. Install the new Dynamic Float Sealing Gasket (7, 11) on the Float. Make sure that it fits perfectly to the housing.
8. Install the Floats (10, 3) to the Body (1):
  - a. In 1" THV, CHV and KHV models, install the Small Orifice Body (12) and Cover (14) to the Small Chamber Box (16) by threading. Move the Small Float (10) and check that the Dynamic Float Sealing (11) perfectly seals the Orifice (12) hole.
  - b. In SHV models, put the Floats (3&7&4) inside the Studs (14) and assemble the Cage Studs (14) to the Cover (2). Make sure that the Dynamic Float Sealing (7) perfectly seals the Orifice (8) hole.
9. Check the Float movement and make sure that it is moving freely.
10. Make sure that there are no residuals or particles inside the Valve body. If so, please clean them.
11. Install the new Body/Small Chamber Box Sealing (19) on the body. Make sure that the gasket perfectly fits on the housing.
12. Install the Cover (2) / Small Chamber Box (16) on the Body (1) and screw the bolts in opposing order.

In PHV Sewage Air Valve Models, please follow the below steps to renew the Float Sealing Gasket (12):

1. Isolate the Valve from the line, and drain the medium. Make sure to fully de-pressurize the pipeline.
2. Remove the bolting on the Cover (2) and take it out from the Body. The whole float assembly shall come out as one item.
3. Remove the Cover Sealing (6).
4. Clean the Body (1) sealing surface and Cover (2) sealing surface.
5. Disassemble the Sealing Air Valve Bottom Piece (13) and Sealing Air Valve Body (15) by unthreading.
6. Remove the Sealing O-ring (14) and clean the sealing surface.



7. Take out the Float (11) and remove the Float Sealing (12). Clean the surface and install the new Sealing.
8. Install the Sealing O-ring (14) and make sure that it fits on the channel perfectly.
9. Check the Float movement and make sure that it is moving freely.
10. Make sure that there are no residuals or particles inside the Valve body. If so, please clean them.
11. Thread the Sealing Air Valve Bottom Piece (13) and Sealing Air Valve Body (15).
12. Install the new Cover Gasket (6) on the body. Make sure that the gasket perfectly fits on the housing.
13. Install the Cover (2) on the Body (1) and screw the bolts in opposing order.

In YHV Underground Air Valve Models, please follow the below steps to renew the Air Valve Body (2):

1. Remove the bolt (22) on the Cover (7) and take the Cover out from the Sleeve (3).
2. Remove the bolt (13) on the T-Nut (8) and take the T-Nut out of the Sleeve (3).
3. By holding from the Pipe (9), take the Air Valve Body (2) Set out. In this process, integral Check Valve (11) mechanism shall act and provide sealing.
4. Remove the Pin (17) from the Air Valve Cover (6) and take the Air Valve Body (2) out.
5. Unthread the Retaining Body (5) at the bottom of the Air Valve Body (2).
6. Renew the Air Valve Body (2) and thread it to the Retaining Body (5).
7. Renew the O-rings (19) on the Retaining Body (5), clean them and fit them to the housings.
8. Assemble the Air Valve Cover (6) on the Air Valve Body (2) and fix them by the Pin (17).
9. Fit the Retaining Body (5) on the O-ring Housing (4), without damaging the O-rings.
10. Fit the T-Nut (8) on the channels of the Sleeve (3) and screw the bolt (13). Make sure that the bolt (13) fits on the Retaining Bolt (10). After this process, Check Valve (11) mechanism shall be in-active and Air Valve Body (2) shall be active. Make sure that there is no water outflow from the Valve.
11. Install the Cover (7) on the Sleeve (3) and screw the bolting (22).

For VCC Vacuum Breaker Models, please check DVD Check Valve Operations Manual.



**dvdvalves**  
“brings life”

## **CONTACT INFORMATION**

---

Doğuş Vana ve Döküm Dis Ticaret Ltd. Sti.

Address: MOSB IV. Kısım Ahmet Nazif Zorlu Bulvarı No: 28 45030 Manisa – TURKEY  
Tel: 00 90 236 213 11 25  
Fax: 00 90 236 213 11 35  
Email: [infodogus@dogusvana.com.tr](mailto:infodogus@dogusvana.com.tr)  
Web: [www.dogusvana.com.tr](http://www.dogusvana.com.tr)